

Instruction manual Digital thermometer Kat. Nr. 30.2028



1. Before you use it

- Please be sure to read the instruction manual carefully.
- Following the instruction manual for use will prevent damage to the device and loss of your statutory rights arising from defects due to incorrect use. We shall not be liable for any damage occurring as a result of not following these instructions.
- Please take particular note of the safety advice!
- Please look after this manual for future reference!
- 2. Field of operation and all of the benefits of your new instrument at a glance
- Temperature measurement in rooms, refrigerator, etc.
- Flexible holder for hanging or standing, with magnet

3. For your safety

- The product is exclusively intended for the field of application described above. The product should only be used as described within these instructions.
- · Unauthorised repairs, modifications or changes to the product are prohibited.
- The product is not to be used for medical purpose or for public information, but is intended solely for home use.



Caution! Risk of injury:

- · Keep this instrument and the battery out of reach of chil-
- · Batteries must not be thrown into the fire, short-circuited, taken apart or recharged. Risk of explosion!
- · Batteries can be fatal if swallowed. If a battery has been swallowed, get medical assistance immediately.
- · Batteries contain harmful acids. Low batteries should be changed as soon as possible to prevent damage caused by a leaking battery.
- Remove the battery if you do not use the product for a lenathy period.
- · Wear chemical-resistant protective gloves and glasses when handling leaked batteries.



Important information on product safety!

• Do not expose the instrument to extreme temperatures. vibration or shock.

- · Clean it with a soft damp cloth. Do not use solvents or scouring agents.
- Protect from moisture.

4. Elements (Fia 1):

A: Buttons:

A 1: ON/OFF button

A 2: °C/°F button

B: Housina:

B 1: Battery compartment B 2: Magnet

B 3: Holder

B 4: Temperature probe

5. Getting started and use

- Pull out the battery compartment and remove the insulation
- Remove the protection foil.
- Press ON/OFF button.
- The display shows the current temperature.
- With the °C/°F button you can choose between °C (Celsius) or °F (Fahrenheit) as the temperature unit.

5.1 Positioning of the thermometer

- · With the fold out holder you can fix it at a suitable place or use the magnet for fixing.
- · Note:

The holder is inserted properly when you hear a "click".

For table standing please fold in the holder.

5.2 Symbol for refrigerator



appears, if the refrigerator temperature is optimal 4°C...8°C (39.2°F...46.4°F).

6. Battery replacement

- When the battery symbol appears, replace the battery.
- Pull out the battery compartment.
- Insert a new battery CR 2025. + pole upwards.

7. Troubleshooting

Solution
 → Switch on the instrument → Ensure battery polarity is correct → Change battery
→ Change battery

If your device fails to work despite these measures contact the supplier from whom you purchased it.

8. Waste disposal



Never dispose empty batteries and rechargeable batteries in household waste. As a consumer, you are legally required to take them to your retail store or to appropriate collection sites depending to national or local regulations in order to protect the environment. The symbols for the heavy metals contained are: Cd=cadmium, Hg=mercury, Pb=lead





This instrument is labelled in accordance with the EU Waste Electrical and Electronic Equipment Directive (WEEE).

Please do not dispose of this instrument in household waste. The user is obligated to take end-of-life devices to a designated collection point for the disposal of electrical and electronic equipment, in order to ensure environmentallycompatible disposal.

9. Specifications

Measuring range:	-20 °C +50 °C (-4 °F+122 °F)
Power consumption:	1 x CR2025 Button cell battery
Housing dimension:	68 x 14 x 60 mm
Weight:	31.65 g (incl. battery)





02/12